

R2036F Assembly Guide

Features

- Standard 2.5", 9.5mm(H) Form Factor
- Support a SATA host & two M.2 NGFF SSD devices
- Built-in ASM1092R high performance processor
- RAID mode switch by hardware strapping or GUI controller
- RAID mode: RAID 0(fast) / RAID 1(safe) / JBOD(volume)
- 3-button Hardware switch to setup RAID mode
- Green LED indicate SATA 3 host active
- Red LED indicate M.2 NGFF SSD error


Before Assembly

- Please read through the installation guide first.
- Please check the accessory list before the integration. Contact your local distributor if you find any parts missing.
- Please retain the original package if you need to return the package for RMA.

Assembling Accessories



		
M3x3 Screw*2	M3x5 Screw*2	M3 Nut*2
		
Copper Nut H: 1.45mm*2	(for Adapter) M2x3 Screw*5	(for Housing) M2x3 Screw*5
		
2.5" Housing (9.5H) *1	R2036F Adapter*1	
Required Tools (Not included)		
All you need to assemble this unit are one screwdriver.		
		

Assembly



**STEP 1.
Make M.2 SSD Stand**
Put copper nut on the same side of the M.2 connector.
Fix with M3x5mm screw from bottom to top of the adapter.

**STEP 2.
Insert M.2 SSD**
Insert M.2 SSD into M.2 67pin connector.
Press down M.2 SSD and aim to the copper nut hole.





**STEP 3.
Fix M.2 SSD**
Use M3 nuts to fix M.2 NGFF SSD on the adapter, namely complete the assembly.

Repeat Step 1~3 for the 2nd M.2 (NGFF) SSD.

If your M.2 SSD is 2280 form factor, pls ignore STEP 1~3.
Use M3x3 Screws 2pcs to fix M.2 NGFF SSD directly.

**STEP 4.
Fix Adapter & Housing**
Assembly the adapter into 2.5" housing with 4pcs of M2x3 screws.



**STEP 5.
Combine 2.5" Housing**
Cover the Top cover.
Use 4pcs of M2x3 screws to fix the housing from broadsides.

RAID mode setup :

- Set RAID mode, you must install both 2 devices; otherwise, it is impossible to set RAID mode.

Set RAID 0 mode :



1	2	3
ON	ON	OFF

Switch SW2 as ON-ON-OFF.
Push SW1 Button to complete the setup.

Start PC, BIOS should show RAID 0 mode (ASMT109x-Fast).

Set RAID 1 mode :



1	2	3
ON	OFF	ON

Switch SW2 as ON-OFF-ON.
Push SW1 Button to complete the setup.

Start PC, BIOS should show RAID 1 mode (ASMT109x-Safe).

Set JBOD mode :



1	2	3
ON	ON	ON

Switch SW2 as ON-ON-ON.
Push SW1 Button to complete the setup.

Start PC, BIOS should show JBOD mode (ASMT109x-Volume).