S2083A Assembly Guide

Before Assembling:

- Please check the accessory list before assembly. Contact your local dealer if you find any parts missing.
- 2. Please read through the assembly guide.

M.2 SSD Accessory Package

(1)M3x3 Screw *1pc P/N: 13MISW00010M11

¶ [for M.2 (2280) SSD]

(2)M3x5 Screw *1pc P/N: 13MISW00005M11

(for M.2 NGFF SSD)

(3)M3 Nut *1pc P/N: 13MINU00002M11

[for M.2 NGFF SSD]

(4)Copper Nut /H: 1.45mm *1pc P/N: 13MICA00001M05

[for M.2 NGFF SSD]



Step 1: Put copper nut on the same side of the NGFF connector; and fix M3x5mm screw from bottom to top of the adapter.

Step 2:Insert M.2 NGFF SSD into M.2 67pin socket.Press down M.2 NGFF SSD and aim to the copper nut hole.

Step 3: Using M3 nuts to fix M.2 NGFF SSDon the adapter namely complete the installation.

If your M.2 NGFF SSD is 2280 form factor, pls ignore step 1. Use M3 x 3 Screw to fix M.2 NGFF SSD.

mSATA SSD Accessory Package

(1)M2x3 Screw *3pcs P/N: 13MISW00005M11



[for Full size SSD]

(2)M2x6mm(H) screw *3pcs P/N: 13MISW00001M11



[for Half size SSD]

(2)Copper Nut /H: 4.0mm *3pcs P/N: 13MICA00001M05




[for Half size SSD]

(3)M2 nut *3pcs P/N: 13MINU00001M11



[for Half size SSD]

The above accessories parts are all have extra 1pc for spare part.



Step1: Put 2pcs of copper nuts(3) on the holes for the half size mSATA SSD and fix with 2pcs of M2x6mm(2) screws.
Insert mSATA SSD into mini PCI-e socket.

Step 2: Press mSATA SSD down and aim to the copper nuts below.

Step 3: Fix mSATA SSD on the adapter with 2pcs of M2*3 screws.

Features

- 2.5" SATA SSD Form Factor: 98 x 65.5mm
- M.2 (NGFF) & mSATA to SATA III Module
- Build in Mini PCI-e 52pin Female connector
- Build in M.2 (NGFF) B key Female connector
- Green LED indicates power status
- Red LED indicates active status
- Insert both M.2 & mSATA SSD on S2083A, M.2 SSD is the first priority. mSATA won't work.